

# Festive

INSTRUCTION USAGE For Battery Operated P054716, P054717, P054718,  
P054719, P054720, P054721, P054724, P054725  
VARIOUS DESIGNS

## **BOX CONTENT:**

1 x Various design item

## **ASSEMBLY INSTRUCTION**

No assembly required.

## **OPERATING INSTRUCTION**

On the battery compartment there is a 3 WAY switch.

- 1.Slide the switch to ON , the lights come on & stay on continuously.
- 2.Slide the switch to OFF, the lights go off.
- 3.Slide the switch to timer function, lights will stay on for 6 hours and then automatically switch itself off and remain off for 18 hours.

## **BATTERY CHANGING:**

Remove the battery cover by holding the compartment in one hand, using your thumb, place on the arrows at the bottom of the compartment cover and push upwards until the cover comes off.

Insert the correct battery type and QTY as per item following the correct polarity.

Place the battery compartment cover back in place.

## **WARNING**

This set is for indoor use only.

For decorative purposes only.

Keep out of the reach of children & pets, it may contain small parts!

An adult must carry out battery replacement and installation.

Check that you have the correct type and quantity of batteries.

Do not short circuit the battery terminals.

Do not modify the battery compartment in any way.

Do not mix used and new batteries.

Do not mix alkaline, standard, lithium or rechargeable batteries.

Remove batteries from product when not in use for long periods of time.

**Festive Productions Limited**

**Otters Brook**

Ty Coch Way

Cwmbran, NP44 7EZ

AB Alrik Hedlund-412 21,

Gothenburg, Sweden

**01633627300**

**[www.festive.co.uk](http://www.festive.co.uk)**

**MADE IN CHINA**



[support@festive.co.uk](mailto:support@festive.co.uk)



[Support-FPL@hedlundgruppen.com](mailto:Support-FPL@hedlundgruppen.com)

# Festive

Store unused batteries in their original packaging.  
Do not recharge non-rechargeable batteries.  
Keep away from heat or a direct flame.  
Install carefully to prevent any damage to the batteries.  
Remove exhausted batteries from this product.

## CARE INSTRUCTION

Clean with a dry cloth.  
Always remove batteries when not in use.  
Always store in dry conditions.

## ELECTRICAL RATING

This set operates on 4.5V DC  
LED non-replaceable bulb rating 3V 0.01A 0.06W

## BATTERY REQUIRED.

3 x AA 1.5V



This Symbol indicates that this product is covered by legislation for waste electrical electronic products. When the product has reached the end of its life, please do not dispose of it with general household waste. Consider the environment and take it to a recognised recycling facility.



Festive Productions Limited  
Otters Brook

Ty Coch Way  
Cwmbran, NP44 7EZ

AB Alrik Hedlund-412 21,  
Gothenburg, Sweden

01633627300  
[www.festive.co.uk](http://www.festive.co.uk)

MADE IN CHINA

 [support@festive.co.uk](mailto:support@festive.co.uk)

 [Support-FPL@hedlundgruppen.com](mailto:Support-FPL@hedlundgruppen.com)