



## Assembly and Usage Instructions for: P051508 – 180CM SNOWMAN - INFINITY LIGHT

### **BOX CONTENTS**

1 X 180CM SNOWMAN. 1 x TRANSFORMER  
2 X MOUNTING BASE (SEE SEPARATE OUTDOOR INSTRUCTIONS SHEET  
FOR INCLUDED FITTINGS)

### **UNPACKING OF ITEM**

PLEASE BE CAREFUL WHEN UNPACKING ITEM AND FITTINGS  
TAKE EXTRA CARE WHEN CUTTING PACKAGING AWAY FROM THE  
TRANSFORMER LEAD, ALWAYS CUT AWAY FROM THE CABLE!  
CHECK THAT YOU HAVE ALL PARTS AND FITTINGS FOR OUTDOOR USE  
BEFORE YOU ASSEMBLE THE ITEM!  
PLEASE RETAIN THE PACKAGING FOR STORAGE

### **ASSEMBLY INSTRUCTIONS**

ON EACH MOUNTING BOARD YOU WILL NOTICE SOME HOLES, YOU  
WILL USE THESE TO MATCH UP ON THE INFINITY ITEM WHICH HAS 2  
HOLES, PLEASE MATCH THESE HOLES UP ON THE MOUNTING BOARD.  
ON THE INFINITY ITEM THERE WILL BE 2 HOLES AT THE BOTTOM OF  
EACH SIDE, MATCH THEM UP WITH THE MOUNTING BOARD HOLES.  
FIRSTLY YOU NEED TO INSERT THE INFINITY ITEM INTO THE  
MOUNTING BOARD MAKING SURE THAT THE HOLES MATCH UP.  
IF YOU ARE HAVING DIFFICULTY GETTING THE ITEM INTO THE  
MOUNTING BASE, LINE UP THE EDGE OF THE INFINITY ITEM WITH THE  
MOUNTING BOARD AND SQUEEZE THE FOAM TOGETHER, THIS SHOULD  
THEN ALLOW YOU TO PUSH THE ITEM INTO THE GROOVE IN THE  
MOUNTING BOARD FOR A TIGHT FIT.  
DON'T FORGET TO MATCH THE HOLES UP.  
REPEAT THIS PROCESS FOR THE NEXT SIDE OF THE ITEM.  
NEXT USE THE SUPPLIED SCREWS WITH WING NUTS, THESE NEED TO  
GO THROUGH THE ITEM AND THE MOUNTING BOARD, ONCE THROUGH,  
TIGHTEN THE WING NUTS.  
FOR OUTDOOR USE, PLEASE USE THE OUTDOOR INSTRUCTIONS, THESE  
ARE ON A SEPARATE SHEET!

## **OPERATING INSTRUCTIONS**

PLUG TRANSFORMER INTO THE WALL SOCKET AND SWITCH ON AT THE SOCKET, THE LIGHTS WILL COME ON.  
TO TURN OFF, SWITCH OFF AT THE WALL SOCKET.

## **WARNINGS**

KEEP AWAY FROM CHILDREN AND PETS!  
DO NOT OPERATE THIS ITEM WHILST STILL IN THE PACKAGING!  
THE LAMPS ON THIS SET ARE NOT REPLACEABLE!  
THE TRANSFORMER MUST BE KEPT INDOORS AT ALL TIMES!  
DO NOT TRY TO CONNECT THIS SET ELECTRICALLY TO ANOTHER SET!  
IF THERE IS ANY DAMAGE OR BREAKAGE TO THE ELECTRIC WIRE,  
PLEASE DISPOSE OF SAFELY!  
THIS LIGHT SET IS SUITABLE FOR INDOOR & OUTDOOR USE!  
BE CAREFUL WHERE YOU LOCATE THIS ITEM, DO NOT LEAVE A TRIP  
HAZARD!

## **CARE**

CHECK FITTINGS REGULARLY TO MAKE SURE THEY ARE TIGHT.  
CHECK CABLES TO MAKE SURE THEY ARE TAUT TO PREVENT THE ITEM  
FROM TIPPING OVER.  
REMOVE BASE AND STORE FLAT WHEN NOT IN USE.  
USE A DRY CLOTH TO CLEAN.

## **ELECTRICAL RATINGS**

INPUT 230-240V ~ 50 HZ

THIS SET OPERATES ON 11.85V AC & 64.42W

TRANSFORMER RATING 12V AC 96W

LED BULB RATING 3V 0.067A 0.2W



### **Festive Productions Limited**

Otters Brook, Ty Coch way,  
Cwmbran NP44 7EZ UK  
AB Alrik Hedlund – 412 21,  
Gothenburg, Sweden

Having difficulty with this  
product? Then contact us on  
our support email.

[www.festive.co.uk](http://www.festive.co.uk)

MADE IN CHINA

Please retain these instructions for future reference

**P051508 Issue 1**

**Festive Technical Support**



[support@festive.co.uk](mailto:support@festive.co.uk)

